Donning and Doffing of COVID-19 PPE Airbone + Contact Precautions PAPR

BEFORE Entering Room: Remove all personal items (jewelry, watches, cell phones, etc.) and secure hair.



Step 1: Perform hand hygiene with alcohol-based hand rub (ABHR)



Step 2: Put on PAPR.



Step 3: Put on gown.

- Insert thumb into thumb hole, if present.
- Tie all ties securely.



Step 4: Put on gloves.

Pull gloves over sleeves to cover wrist.



Keep gloved hands away from face and avoid unnecessary touching of objects or surfaces.



Step 4: Remove PAPR hood.

Lean forward slightly and grasp at back of head. Pull forward and down to remove. Do not touch the front of PAPR.





Step 6: Put on clean gloves to remove and disinfect PAPR equipment. Refer to site procedure for hood disinfection and re-use



Step 7: Remove gloves and discard in trash.



EXITING PATIENT ROOM INSIDE Patient Room

Step 1: Remove gloves and gown.



- Remove gloves (unless using gown with thumb holes). Perform hand hygiene with ABHR.
- Untie gown in back (or have buddy untie).
- Grasp shoulders of gown and pull forward with a quick firm tug.
- Roll outside of gown inward, folding contaminated outside layer away from body.
- If using gown without thumbholes: remove gown. Avoid contaminating hands.
- Discard gown in trash (if disposable) or soiled linen (if reusable).
- If using gown with thumbholes: Remove gloves while rolling off gown. Avoid contaminating hands. Keep hands on clean side of gown. Discard gown and gloves in trash.



Step 2: Perform hand hygiene with ABHR and exit patient room/area.

OUTSIDE the Patient Room

Step 3: Disconnect hose at top of head (use a buddy, if possible).



Step 5: Perform hand hygiene with ABHR.



Step 8: Perform hand hygiene with ABHR.



Revised 3/14/20